

USER MANUAL Fixturlaser NXA GEOMETRY



**Fixturlaser**

ACOEM Group



# CONTENT

Welcome to our world	1.1
Declaration of Conformity	2.1
Main Menu	3.1
Straightness Measurement	4.1
Rectangular Flatness Measurement	5.1
Circular Flatness Measurement	6.1
Memory Manager	7.1
Receiver R2	8.1
Laser Transmitter T110	9.1
Laser Transmitter T111	10.1
Laser Transmitter T21	11.1
Laser Transmitter T220	12.1
Technical Specification R2	13.1
Technical Specification T110	14.1
Technical Specification T111	15.1
Technical Specification T21	16.1
Technical Specification T220	17.1



## **WELCOME TO OUR WORLD**

*Since the very beginning in 1984, ACOEM AB (formerly known as ELOS Fixturlaser AB) has helped industries throughout the world to achieve more profitable and sustainable production. We have reached where we are today by having the courage to think beyond the norm and follow slightly unconventional paths. We have had the courage to make mistakes and find new directions. Through our resolve, ambition and knowledge we have become a global player and a leader in innovative, user-friendly shaft alignment.*

## **SUSTAINABLE INNOVATIONS**

During our almost 30 years in this industry, we have explored, tweaked and tested more than anyone. Some might say we are incurable innovators whereas others might

say that we are highly focused. They both probably have a point. If we had not been devoted and ambitious, we would not have been the first in the industry to have a touch screen. Nor would we have been pioneers in the use of visible lasers and dual measurement heads.

Over the years, we have learnt to never compromise on quality and we are constantly in search of new, unexplored opportunities by combining advanced technology with design and function. By doing so, we have become the leading innovator in our industry. Not only do we minimize wear, production stoppages and costs, we also help save the environment. Natural resources are in short supply and if we can contribute to a more sustainable

world by making it a little bit straighter, we couldn't be happier.

## **TRUE COMMITMENT**

One reason for our success is our solid commitment. We have ensured that we remain attentive to constantly pick up on the needs of the market. Our expert employees and dedicated dealers in over 70 countries are undoubtedly our most important asset. Satisfaction and team spirit are of particular importance to us and are consistently at the top of our priority list. With experience from a wide range of industries and manufacturing processes, we are fully aware of the problems and needs of our end-customers. We are passionate about what we do and we are driven by the desire to eliminate anything in the industry

worldwide that may be even slightly out of line.

## **PURE USABILITY**

Our design and user-friendliness are carefully interwoven. As we develop new products, they also become cleaner, smarter, more functional and more robust. An industrial environment is demanding, infinitely more difficult to work in and inevitably subject to time pressure. There is no place for equipment with unnecessary functions, complicated interfaces and that is difficult to assemble.

Usability and user friendliness mean everything, not only to us but also to our customers. We have designed products that are easy to learn and can be incorporated quickly. By removing non-essential functions,

we make life less difficult for our users – and probably a little more difficult for our competitors.

## **END USER LICENSE AGREEMENT**

The rights to use the software in this product are offered only on the conditions that you agree to all the terms stated below, i.e. the end user agreement. By using this product you agree to be bound by this agreement. If you do not accept this agreement your sole remedy is to return the entire unused product, hardware and software, promptly to your place of purchase for a refund.

The user is granted a single license to use the software contained in this product. Use is only permitted on the hardware it has been installed on at the time of purchase. The software may not be removed from the hardware.

The software contained in the system is the property of ACOEM AB, any copying or redistribution is strictly prohibited.

Modifying, disassembling, reverse engineering or decompiling the system or any part thereof is strictly prohibited.

Disclaimer of warranties: To the maximum extent permitted by applicable law, ACOEM AB and its suppliers provide the software contained in this product 'as is' and with all faults, and hereby disclaim all other warranties either expressed, implied or statutory.

Limited liability: No liability shall exceed the price of the product, and the sole remedy, if any, to any claim shall be a right of return and refund.



ACOEM AB or its suppliers shall, to the maximum extent permitted by applicable law, not be liable to any indirect, special, incidental, punitive, and consequential damages arising from the use of the system or any part thereof, authorized or unauthorized.

ACOEM AB (formerly known as Elos Fixturlaser AB) is since mid-2014 a fully owned subsidiary of ACOEM Group, headquartered in Lyon, France. Other brands within ACOEM Group are 01 dB, ONEPROD and METRAVIB. For more information please visit [www.acoemgroup.com](http://www.acoemgroup.com)



## **DECLARATION OF CONFORMITY**

In accordance with  
2014/35/EU Low Voltage Directive  
2014/53/EU Radio Equipment Directive  
2012/19/EC Waste electrical and electronic equipment (WEEE)  
2011/65/EU Restriction of the use of certain hazardous substances (RoHS)  
2006/66/EU Battery Directive  
2001/95/EC CE marking directive

### **Type of equipment**

Alignment System

### **Brand name or trade mark**

FIXTURLASER NXA Geometry

### **Type designation(s)/Model no(s)**

I-1121 FIXTURLASER R2  
I-0390 FIXTURLASER T110  
I-0285 FIXTURLASER T111  
I-0897 FIXTURLASER T21  
I-0289 FIXTURLASER T220

### **Manufacturer's name, address, telephone & fax no**

ACOEM AB  
Box 7  
SE-431 21 Mölndal  
Sweden

Tel: +46 31 7062800  
Fax: +46 31 7062850

The following standards and/or technical specifications, which comply with good engineering practice in safety matters in force within the EEA, have been applied:

**Standard/Test report/Technical construction file/Normative document**

EN 61000-6-3:2007.

EN 61000-6-2:2005, EN 61000-4-2, -3, -4, -5, -6, -11.

EN 61010-1:2010

ISO9001:2015 Ref. No/ Issued by: DNV Certification AB Certification No. 2009-SKM-AQ-2704/2009-SKM-AE-1419.

The laser is classified in accordance with the International Standard IEC-60825-1:2014, USA FDA Standard 21 CFR, Ch I, Part 1040.10 and 1040.11 except for deviations

pursuant to laser notice No. 50, dated June 24, 2007.

The wireless device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions;

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

**Additional information**

The product was CE-marked in 2013.

As manufacturer, we declare under our sole responsibility that the equipment follows the provisions of the Directives stated above.

**Date and place of issue**

Möln dal 2019-09-13

Signature of authorized person

A handwritten signature in black ink, appearing to read 'Hans Svensson', written in a cursive style.

Hans Svensson, Managing Director



## MAIN MENU

The FIXTURLASER NXA is available with different programs for specific purposes. The programs included depend upon which application packages and accessories you have selected.



Press the ON button to start the system and the Main Menu appears.



In the Main Menu you can select the program that you want to use.

In the Main Menu you will also find the Memory Manager and Global Settings.

## APPLICATION PROGRAMS



Shaft Alignment Horizontal  
Machines



Shaft Alignment Vertical  
Machines



Shaft Alignment Offset  
Machines



Machine Train Alignment



Softcheck



Target Values



OL2R



Hot Check



Target Values Clock



Straightness Measurement



Rectangular Flatness  
Measurement



Circular Flatness  
Measurement



Sensor Display





Sensor Display ROP



Max Min ROP



Text Editor



Machine Defined Data

## MEMORY MANAGER



Memory Manager

## SYSTEM FUNCTIONS



Global Settings



Bluetooth Indicator



Backlight



Battery Status



Off





## STRAIGHTNESS MEASUREMENT

### INTRODUCTION

In the Straightness Measurement program, straightness can be measured in two axes. The laser beam is used as reference and the deviation in distance between the laser beam and the measurement object is measured in two or more positions, with the use of the receiver.

## MEASUREMENT METHODS

In the Straightness Measurement program, there are different measurement methods. Measurement method is selected in the measurement point window.



### Standard Straightness

The laser beam is set roughly parallel to a surface or an object. Two points are used as references.



### Straightness with the Clock method as reference

The laser beam is set roughly parallel to a centre line. Two points are used as references. The receiver is rotated 180

degrees in each measurement point to find the centre of the measurement object.



### **Straightness with the Arc Angle Method**

The laser beam is set roughly parallel to a centre line. Two points are used as references. The receiver is placed in 3 to 9 positions at each measurement point to find the centre of the measurement object.



### **Rotate Laser Straightness**

The laser transmitter is placed on the rotating object. The laser beam is adjusted until it is roughly collinear with the

axis of rotation. The receiver is fixated onto the measurement object and measurement points are taken while moving measurement object. At each measuring point, 2 recordings are done by rotating the laser beam 180 degrees.

## **MOUNTING**

See chapters about receivers and laser transmitters.

## **CONNECTING RECEIVER**

See chapter about receiver R2.

## **STARTING THE PROGRAM**



Start the program by touching the Straightness Measurement icon in the Main Menu.



Go to Settings for selecting settings.

## SETTINGS



These settings are unique for this application.

For most of the settings, the current selection is shown in the icon.

The functions that are available depend upon which application packages and accessories you have selected.

## Resolution shown



Opens window for selection of resolution shown.

## Sampling time



Opens window for selection of sampling time.

A repeatability test can also be made here. See chapter “Repeatability test”.

## Best fit



Opens window for selection of best fit type; Y axis only or Y and X axis.

## Angle format



Opens window for selection of angle format.

## Global settings




Opens Global settings. See chapter “Global settings”.

## Confirm



Exits the Settings and returns to the application.

## CONFIGURATION



Up to 99 points can be measured.

Number of points is selected by entering distances between them, starting from point 1.

Equal distances can be entered by entering them at the last point (the furthest from point 1). The same distance will then be filled in in all empty boxes towards point 1.

## Enter distances



Touch and release the icon to enter distances.

Measure and enter distances between measurement points.

If most of the distances are unequal they can be entered one by one without exiting the input window, by changing the distance input to “next”.



Touch the icon to change distance input to “next”.

## Scroll



Scroll for more points.





## Change configuration

Distances can be changed.



Touch and release the icon to change a distance.

The last distance can be deleted if there are no measured points beyond it.



Touch the delete icon to remove a distance.


## COARSE ADJUSTMENT

### Standard Straightness

1. Position the laser transmitter at one end of the measurement object, on the object or on a tripod.
2. Position the receiver as close as possible to the laser transmitter. Adjust the height of the laser transmitter and the receiver until the laser beam hits the centre of the target.




3. Move the receiver as far from the laser transmitter as possible but still on the measurement object. Adjust the laser beam with the adjustment screws on the laser transmitter until it hits the centre of the target. Repeat until the laser beam hits the target at both ends of the measurement object.




## Straightness with the Clock method

1. Locate the approximate centre of the bore with a tape measure and place the receiver at this centre.
2. Position the laser transmitter as close as possible to the first bore so that the laser beam hits the centre of the target.




3. Rotate the receiver and the probe 180° and slide it to correct half of the difference between the laser spot and the centre.



4. Adjust the laser transmitter so that the laser beam hits the centre of the target.

5. Move the receiver to the last bore. Adjust the angle of the laser beam with the adjustment screws until it hits the centre of the target.




to the last measurement point and adjust the angle of the beam.

6. Move the receiver to the first measurement point.

If the laser beam does not hit the centre of the target, adjust the laser transmitter and then move the receiver


## Straightness with the Arc Angle method

1. Place the laser transmitter as close as possible to the first bore. Make sure that the transmitter and its fixture is firmly attached to the casing.



2. Adjust the position of the laser, sideways and in height, until the laser beam is within 1-2 mm from the centre of the first reference bore, by using the

tape measure.



3. Adjust the angle of the laser beam, horizontally and vertically, by using the micrometer screws on the laser transmitter to position it in the centre of the second reference bore. Use a tape measure to position the beam into the centre within 1-2 mm.

4. If necessary, repeat the procedure for coarse adjustment until the beam is centred in both reference bores.

## Rotate Laser Straightness

1. Mount the laser transmitter as close as possible to the center of the rotating reference object. Make sure that the laser transmitter is firmly fixated to the reference object.
2. Place the receiver on the measurement object and place it as close as possible to the laser transmitter and adjust its position until the laser beam hits the center of the target (within 1-2 mm).
3. Rotate the reference object with the laser 180 degrees. The laser beam will move during rotation and describe a half circle pattern. The center point of the line between the starting and end point will be the center of rotation.
4. Adjust the position of the laser vertically and horizontally until it hits the center of rotation (1-2 mm).
5. Move the measurement object as far as possible.
6. Mark the position where the laser beam hits the target. If the laser is outside the target, place a piece of paper board in front of it and make a mark.
7. Rotate the reference object 180 degrees. The laser beam will move during rotation and describe a half



circle pattern. The center point of the line between the starting and end point will be the center of rotation.

8. Adjust the angle of the laser beam with the two micrometer screws on the laser transmitter until it hits the center point.


## **REPEATABILITY TEST**

Before starting the straightness measurement, we recommend that you perform a repeatability test. See chapter “Repeatability Test” in FIXTURLASER NXA manual.

Do the repeatability test at a position far from the laser transmitter.

## MEASUREMENT

### Summary screen



The summary screen shows all the measurement points.

The measurement point registration is done in the measurement point screen.

- Touch and release a point to open the measurement point screen.

The touched point is marked in green.


If you want to change configuration, it is possible to return to the configuration.



Touch and release the configuration icon to go to configuration.

## Measurement method



Measurement method is selected in the measurement point window.



Opens window for selection of measurement method. Standard Straightness, Straightness with the Clock method, Straightness with the Arc Angle method, or Rotate Laser Straightness.

## Measurement point registration - Standard Straightness

Place the receiver on the point to be measured. Make sure that the laser beam hits the target.



Live values are indicated with a green vertical line beside the values.



Touch the register icon to register the measurement point.

The colour indicates the status of the Y and X values in relation to the selected tolerance.



Within tolerance.



Positive values within double tolerance.




Negative values within double tolerance.



Positive values out of double tolerance.



Negative values out of double tolerance.



When a measurement point is registered, fixed values are indicated without a green vertical line beside the values.

## Note

A note with up to 20 characters can be entered at each point.





Touch the icon for entering a note.

## Neighbor points

It is possible to continue directly to a neighbor point direct in the measurement point screen. In other words, it is not necessary to return to the summary screen between each point.

Touch a neighbor point to go to it.

-  Unmeasured neighbor point.
-  Measured neighbor point.

## Remeasure a point



Touch the remeasure icon.

## Delete a point



Touch the delete icon.

## Return to summary screen



Touch the confirmation icon to return to summary screen.

## Measurement point registration - Straightness with the Clock method


Using this method, the procedure at every measurement point is made in two steps.

For each measurement point, measurement values have to be taken in 2 positions.


Important: Make sure that the entire laser beam falls inside the detector area of the receiver at both positions, before starting the registration.

Note: The clock method with measurements only at 12 and 6 o'clock are not recommended for larger diameter bores (i.e. diameter over approximately 250 mm), or when there are worn surfaces in bottom of bores and/or errors in roundness.

Place the receiver and the probe upside-down and in level.









Live values are indicated with a green vertical line beside the values.



Register the values in the position before rotation. The Y and X values will be zeroed.

Rotate the receiver and the probe 180° (in level).





Register the values in the position after rotation. The Y and X values will be halved.

When a measurement point is registered, fixed values are indicated without a green vertical line beside the values. The colour indicates the status of the Y and X values in relation to the selected tolerance.

## **Measurement point registration - Straightness with the Arc Angle method**


Using the Arc Angle method, the procedure at every measurement point is made in several steps.

For each measurement point, measurement values have to be taken in 3 positions and can be taken in up to 9 positions.

Important: Make sure that the entire laser beam falls inside the detector area of the receiver at all positions, before starting the registration.

Place the receiver at the first position and make sure that it is properly attached to the surface.





Live values are indicated with a green vertical line beside the values.




Register the values at the 1st position, by touching the icon for registration of positions in the Arc Angle method.

Rotate the receiver to a 2nd appropriate position.




Minimum angle between positions is 30 degrees. Green sector show permitted positions. Red sector show forbidden positions.




Rotate the receiver to the 3rd appropriate position.



Register the values at the 2nd position.




Register the values at the 3rd position.



Rotate the receiver to another position or confirm Arc Angle measurement and show result for the point.



Finish Arc Angle measurement and show result for the point.



When the Arc Angle measurement is finished, a list of the values at each position is shown together with the result. This list will not be saved but it is possible to take a screen dump of it.

Fixed result values are indicated without a green vertical line beside the values. The colour indicates the status of the Y and X values in relation to selected tolerance.


## Measurement point registration – Rotate Laser Straightness

Using this method, the procedure at every measurement point is made in two steps.


For each measurement point, measurement values have to be taken in 2 positions, before and after rotating the laser 180°.

Important: Make sure that the entire laser beam falls inside the detector area of the receiver at both positions, before starting the registration.

Place the laser (in level)









Live values are indicated with a green vertical line beside the values.




Register the values in the position before rotation.

Rotate the laser 180° (in level).





Register the values in the position after rotation.



When a measurement point is registered, fixed values are indicated without a green vertical line beside the values. The colour indicates the status of the Y and X values in relation to the selected tolerance.

## REFERENCES

There are different ways to select references.

### Manually selected reference points

One or two points that can be selected in the measurement point screen.



Select point as reference.

### Best fit

Contrary to the selection of reference points, best fit is a function that can be enabled or disabled. The function calculates a reference line that minimizes the deviation from measured points. In straightness, a minimum of two measured points is required for the function to be accessible. When the function is enabled, it will

continuously recalculate a reference line or plane whenever the input parameters to the function are changed. These parameters are changed if a new point is measured, a point is remeasured, a measured point is removed or if a user given distance is changed. The best fit reference line will however not be recalculated if the user aligns a measured point.



Enable the best fit function.



Update best fit calculations.



Disable the best fit function.

## MEASUREMENT RESULT

### Summary screen



The summary screen shows all the measurement points.

The diagram scale is automatically adjusted according to the highest or lowest Y or X value.

The symbols indicate status of the measurement point.

- Values within tolerance.
- Positive values within double tolerance.
- Negative values within double tolerance.
- Positive values out of double tolerance.
- Negative values out of double tolerance.
- Unmeasured point.
- Reference point.

Tolerance, maximum and minimum values and the difference between the maximum and minimum values are also shown.

Measurement values for each point can be seen in the measurement point screen or in the list screen.



Touch and release a point to open the measurement point screen.



Touch the list icon to go to list.


## Save measurement

The measurement can be saved anytime and be opened later.



Touch the save icon to save the measurement.

## List screen



		Y	X	
1	0	0.000	0.000	-0.5
2	200	-0.030	+0.013	-0.5
3	400	-0.029	+0.009	-0.5
4	600	-0.037	+0.018	-0.5
5	800	-0.082	-0.088	-0.5
6	1300	-0.120	-0.073	-0.5
7	1500	-0.119	-0.076	-0.5
8	1700	-0.149	-0.012	-0.5
9	1900	-0.103	-0.013	-0.5
10	2100	-0.063	+0.074	-0.5
11	2600	-0.021	-0.034	-0.5
12	2800	+0.023	+0.074	-0.5
13	3000	+0.057	+0.094	-0.5



Touch the summary screen icon to return to summary screen.

The list screen shows all the measurement points in a list with distances, values and notes if any.

The list can be scrolled up and down with a finger or by using the arrows at the right.

## Evaluating the result

The result is presented in relation to the selected references. The direction is depending on how the receiver is placed. If the receiver is placed according to the mounting instructions, Y values are showing the vertical direction and X values the horizontal direction. In the vertical direction (Y), positive values mean that the measurement object at this point is higher than the reference line and negative values that the measurement object is lower than the reference line.


In the horizontal direction (X, looking at the receiver from the laser transmitter), positive values mean that the measurement object at this point is to the left and negative values that the measurement object is to the right.

These values are compared with the tolerance to determine whether correction is necessary. When a tolerance is selected, the symbols indicate if the values are within tolerance or not.


In the diagrams, upwards correspond to positive values.

## ALIGNMENT


Select the point to be aligned in the summary screen.



Place the receiver on the point. Make sure that the laser beam hits the target.



Standard  
Straightness



Straightness  
with the  
Clock  
method



Straightness  
with the  
Arc Angle  
method






Rotate  
Laser  
Straightness



Touch the alignment icon.

Note: Make sure that the receiver is placed in the correct position on the right point before confirming to go to live adjustment.



The actual values for the selected point go live and alignment can be made towards zero. Zero will be in accordance to selected references.

Adjust vertically and horizontally until the Y and X values for the selected measurement point are within tolerance.

The arrows show in which direction to adjust.




Confirm the alignment.


Note: Depending on your application, alignment at one point might affect other measurement points. It is therefore recommended to remeasure all points when all adjustments are made.

## STRAIGHTNESS TARGET VALUES


The function Straightness Target Values makes it possible to enter Target Values at the measurement points in the Straightness program.



Touch the Target Value icon to enter Target Values.



Enter Target Values and confirm.



Entered Target Values are shown in the measurement screen.

A screenshot of a list view showing target values for a straightness function. The list has five columns: a selection column, a distance column, a Y coordinate column, an X coordinate column, and a Z coordinate column. The data rows are as follows:

		Y	X	Z
1	0	0.000	0.000	0.0
2	500	+0.097	-0.169	-0.1
3	1000	-0.001	-0.079	-0.1
4	1500	+0.097	+0.230	-0.1
5	2000	+0.100	-0.137	-0.1
10	4500	0.000	0.000	0.0

Below the table, there are icons for a left arrow, a pencil/eraser, a double arrow, and a folder.

When the Straightness Target Value function is selected the Target Values are shown in the list (instead of notes).

## OTHER FEATURES

### Turn off X diagram

When measuring in the Y axis only, the X diagram can be turned off. The diagram scale will then be automatically adjusted according to the highest or lowest Y value only.



Turns off X diagram.

### Sensor display

Sensor Display can be reached directly in the summary screen.



Starts Sensor Display.

See chapter "Sensor Display" in the FIXTURLASER NXA manual.

### Reference Receiver

A reference receiver, a second receiver, is used in applications where you want to check that the reference, the laser beam, has not moved during the measurement sequence.

The reference receiver is normally mounted at far distance from the laser transmitter to more easily detect any movements of the laser.

When the laser beam is adjusted to its final position and the reference is established, the values from the reference receiver are set to zero in the Sensor Display. It is possible, at any time during the measurement, to enter the Sensor Display and check that the values are still zero.

See chapter “Receiver R2” about connecting a reference receiver.



## RECTANGULAR FLATNESS MEASUREMENT

### INTRODUCTION

In the Rectangular Flatness Measurement program a laser plane is used as reference. The deviation in distance between the laser plane and the measurement object is measured in one or more positions with the use of the receiver.

The laser plane can either be created by three reference points or by levelling, with the laser plane put in level and with one measurement point as reference.

### MOUNTING

See chapters about the receiver and laser transmitters.

### CONNECTING RECEIVER

See chapter about receiver R2.

### STARTING THE PROGRAM



Start the program by touching the Rectangular Flatness Measurement icon in the Main Menu.



Go to Settings for selecting settings.

## SETTINGS



These settings are unique for this application.

For most of the settings, the current selection is shown in the icon.

The functions that are available depend upon which application packages and accessories you have selected.

### Resolution shown



Opens window for selection of resolution shown.

### Sampling time



Opens window for selection of sampling time.

A repeatability test can also be made here. See chapter “Repeatability test”.

### Angle format



Opens window for selection of angle format.



## Global settings





Opens Global settings. See chapter “Global settings”.

## Confirm



Exits the Settings and returns to the application.

## CONFIGURATION



Up to 15 x 10 points can be measured.

Number of points is selected by entering distances between them, starting from point A1.


Equal distances can be entered by enter them at the last point (the farthest from point A1). The same distance will then be filled in in all empty boxes towards point A1.

## Enter distances




Touch and release the icon to enter distances.

Measure and enter distances between measurement points.



The selected area is marked in green.

## Tolerance



Opens window for selection of tolerance.

## Notes



Opens Notes, where notes can be entered.

## Confirm configuration



Confirms the configuration and continues to summary screen.

## Save configuration

The configuration (distances and tolerance) can be saved separately, to be opened up later.



Touch the save icon to save the configuration.

## Change configuration

Distances can be changed.



Touch and release the icon to change a distance.

The last distance in the row or column can be deleted if there are no measured points beyond them.



Touch the delete icon to remove a distance.

## COARSE ADJUSTMENT

### Three reference points

1. Position the laser transmitter at one end of the measurement object, on the object or on a tripod.
2. Mark the measurement points and name them as they will be shown in the flatness software (A1, A2 etc).
3. Position the receiver as close as possible to the laser transmitter. Adjust the height of the laser transmitter and the receiver until the laser beam hits the centre of the target.
4. Move the receiver to a second point on the measurement object far from the transmitter. Adjust the angle of the laser beam, with one of the adjustment screws, until it hits the centre of the target.
5. Move the receiver to a third point on the measurement object in a direction perpendicular to the other two points far from the transmitter. Adjust the angle of the laser beam, with the second adjustment screw, until it hits the centre of the target.
6. Repeat the procedure until the laser beam hits the centre of the target at all three points. Check that the beam falls into the target centre at all measurement points before starting the flatness measurement.

### **One reference point – Levelling**

To check how a surface is positioned according to level, it is necessary to set the laser plane in level. This is done by zeroing the levels with the micrometer screws.


### **REPEATABILITY TEST**

Before starting the flatness measurement, we recommend that you perform a repeatability test. See chapter “Repeatability Test” in FIXTURLASER NXA manual.

Do the repeatability test at a position far from the laser transmitter.

## MEASUREMENT

### Summary screen



The summary screen shows all the measurement points.

The measurement point registration is done in the measurement point screen.

- Touch and release a point to open the measurement point screen.

The touched point is marked in green.


If you want to change configuration it is possible to return to the configuration.



Touch and release the configuration icon to go to configuration.

## Measurement point registration

Place the receiver on the point to be measured. Make sure that the laser beam hits the target.



Live values are indicated with a green vertical line beside the values.



Touch the register icon to register the measurement point.



The colour indicates the status of the Y value in relation to the selected tolerance.



Within tolerance.



Positive values within double tolerance.



Negative values within double tolerance.



Positive values out of double tolerance.



Negative values out of double tolerance.



When a measurement point is registered, fixed values are indicated without a green vertical line beside the values.

## Note

A note with up to 20 characters can be entered at each point.





Touch the icon for entering a note.

## Neighbor points

It is possible to continue directly to a neighbor point in the measurement point screen. In other words, it is not necessary to return to the summary screen between each point.

Touch a neighbor point to go to it.

-  Unmeasured neighbor point.
-  Measured neighbor point.

## Remeasure a point



Touch the remeasure icon.

## Delete a point



Touch the delete icon.

## Return to summary screen



Touch the confirmation icon to return to summary screen.

## REFERENCES

There are different ways to select references.

### Manually selected reference points

One or three points can be selected in the measurement point screen.



Select point as reference.

### Reference points for positive values only

Selects reference points for positive values only. When selecting positive values only, suitable reference points are automatically selected. Can be selected in the summary screen. Use only after points has been measured.



Select reference points for positive values only.

### Reference points for negative values only

Selects reference points for negative values only. When selecting negative values only, suitable reference points are automatically selected. Can be selected in the summary screen. Use only after points has been measured.



Select reference points for negative values only.

### Best fit

Contrary to the selection of reference points, best fit is a function that can be enabled or disabled. The function calculates

a reference plane that minimizes the deviation from measured points. In flatness, a minimum of three measured points is required in order for the function to be accessible. It is also required that not all the measured points lie on a straight line in order for the function to be accessible. When the function is enabled, it will continuously recalculate a reference plane whenever the input parameters to the function are changed. These parameters are changed if a new point is measured, a point is remeasured, a measured point is removed or if a user given distance is changed. The best fit reference plane will however not be recalculated if the user aligns a measured point.



Enable the best fit function.




Update best fit calculations.



Disable the best fit function.









## MEASUREMENT RESULT

### Summary screen



The summary screen shows all the measurement points.

The symbols indicate status of the measurement point.

-  Values within tolerance.
-  Positive values within double tolerance.
-  Negative values within double tolerance.
-  Positive values out of double tolerance.
-  Negative values out of double tolerance.
-  Unmeasured point.
-  Reference point.
-  Inactive reference point.

Tolerance, maximum and minimum values and the difference between the maximum and the minimum values are also shown.

Measurement values for each point can be seen in the measurement point screen or in the list screen.



Touch and release a point to open the measurement point screen.



Touch the list icon to go to list.


## Save measurement

The measurement can be saved anytime and be opened later.



Touch the save icon to save the measurement.

## List screen



			Y	X		
A1	0	0	0.000	+0.350	0.4	NN
A2	0	150	-0.026	-4.887	0.3	
A5	0	500	+0.074	+0.244	-0.4	
A6	0	650	0.000	-0.079	-0.5	SW
B1	150	0	-0.035	-4.887	-0.4	
B2	150	150	+0.110	-0.959	0.4	
B5	150	500	+0.112	-0.313	0.4	
B6	150	650	+0.090	+0.245	0.4	
C3	450	250	+0.124	-0.959	0.4	
C4	450	400	+0.242	-0.130	0.4	
D3	600	250	+0.176	-1.025	0.4	
D4	600	400	+0.224	+0.226	0.4	
E1	850	0	-0.120	-1.577	0.4	



Touch the summary screen icon to return to summary screen.

The list screen shows all the measurement points in a list with distances, values and notes if any.

The list can be scrolled up and down with a finger or by using the arrows at the right.

## Evaluating the result


The result is presented in relation to the selected references. The direction is depending on how the receiver is placed. If the receiver is placed according to the mounting instructions, Y values are showing the vertical direction. In the vertical direction (Y), positive values mean that the measurement object at this point is higher than the reference plane, and negative values that the measurement object is lower than the reference plane.

These values are compared with the tolerance to determine whether correction is necessary. When a tolerance is selected, the symbols indicate if the values are within tolerance or not.




## ALIGNMENT

Select the point to be aligned in the summary screen.




Place the receiver on the point. Make sure that the laser beam hits the target.



Touch the alignment icon.

Note: Make sure that the receiver is placed in the correct position on the right point before confirming to go to live adjustment.



The actual Y value for the selected point goes live and alignment can be made towards zero. Zero will be in accordance to selected references.

Adjust vertically until the Y value for the selected measurement point is within tolerance.

The arrow show in which direction to adjust.



Confirm the alignment.

Note: Depending on your application, alignment at one point might affect other measurement points. It is therefore recommended to remeasure all points when all adjustments are made.

## OTHER FEATURES

### Sensor display

Sensor Display can be reached directly in the summary screen.



Starts Sensor Display.

See chapter "Sensor Display" in the FIXTURLASER NXA manual.

### Reference Receiver

A reference receiver, a second receiver, is used in applications where you want to check that the reference, the laser beam, has not moved during the measurement sequence.

The reference receiver is normally mounted at far distance from the laser transmitter to more easily detect any movements of the laser.

When the laser beam is adjusted to its final position and the reference is established, the values from the reference receiver are set to zero in the Sensor Display. It is possible, at any time during the measurement, to enter the Sensor Display and check that the values are still zero.

See chapter “Receiver R2” about connecting a reference receiver.



## **CIRCULAR FLATNESS MEASUREMENT**

### **INTRODUCTION**

In the Circular Flatness Measurement program, a laser plane is used as reference. The deviation in distance between the laser plane and the measurement object is measured in one or more positions with the use of the receiver.

The laser plane can either be created by three reference points or by levelling, with the laser plane put in level and with one measurement point as reference.

### **MOUNTING**

See chapters about the receiver and laser transmitters.

### **CONNECTING RECEIVER**

See chapter about receiver R2.

### **STARTING THE PROGRAM**




Start the program by touching the Circular Flatness Measurement icon in the Main Menu.



Go to Settings for selecting settings.

## SETTINGS



The settings are unique for this application.

For most of the settings, the current selection is shown in the icon.

The functions that are available depend upon which application packages and accessories you have selected.

### Resolution shown



Opens window for selection of resolution shown.

### Sampling time



Opens window for selection of sampling time.

A repeatability test can also be made here. See chapter “Repeatability test”.

### Best fit



Opens window for selection of Best fit type.

Best fit based on all circles (ABC) or one circle (A, B or C).

## Angle format



Opens window for selection of angle format.

## Flange measurement



Opens window for activating or de-activating Flange measurement.

## Global settings





Opens Global settings. See chapter “Global settings”.

## Confirm



Exits the Settings and returns to the application.

## CONFIGURATION



Up to 3 circles with 99 points on each circle can be measured.

Number of points is selected by entering diameters and number of points on a circle.



## Enter diameters and number of points on a circle




Touch and release the icon to enter diameters.

Measure and enter diameters.




Touch the icon to enter number of points on a circle.



The selected area is marked in green.

## Tolerance



Opens window for selection of tolerance.

## Notes



Opens Notes, where notes can be entered.

## Confirm configuration



Confirms the configuration and continues to summary screen.

## Save configuration

The configuration (diameters number of points on a circle and tolerance) can be saved separately, to be opened up later.



Touch the save icon to save the configuration.

## Change configuration

The diameters and number of points on a circle can be changed. When measurement point registration has started, number of points can only be changed to a multiple of the origin number of points.



Touch and release the icon to change a diameter.



Touch the icon to change number of points on a circle.

Circles can be deleted if there are no measured points on them.



Touch the delete icon to remove a circle.

## COARSE ADJUSTMENT

### Three reference points

1. Position the laser transmitter at one end of the measurement object, on the object or on a tripod.
2. Mark the measurement points and name them as they will be shown in the flatness software (A1, A2 etc).
3. Position the receiver as close as possible to the laser transmitter. Adjust the height of the laser transmitter and the receiver until the laser beam hits the centre of the target.
4. Move the receiver to a second point on the measurement object far from the transmitter. Adjust the angle of the laser beam with one of the adjustment screws until it hits the centre of the target.
5. Move the receiver to a third point on the measurement object in a direction perpendicular to the other two points far from the transmitter. Adjust the angle of the laser beam with the second adjustment screw until it hits the centre of the target.
6. Repeat the procedure until the laser beam hits the centre of the target at all three points. Check that the beam falls into the target centre at all measurement points before starting the flatness measurement.

### **One reference point – Levelling**

To check how a surface is positioned according to level, it is necessary to set the laser plane in level. This is done by adjusting the micrometer screws on the laser transmitter and by using the built-in spirit level in both directions.


### **REPEATABILITY TEST**

Before starting the flatness measurement, we recommend you to perform a repeatability test. See chapter “Repeatability Test” in the FIXTURLASER NXA manual.

Do the repeatability test at a position far from the laser transmitter.

## MEASUREMENT

### Summary screen



The summary screen shows all the measurement points.

The measurement point registration is done in the measurement point screen.

- Touch and release a point to open the measurement point screen.

The touched point is marked with green.


If you want to change configuration, it is possible to return to the configuration.



Touch and release the configuration icon to go to configuration.

## Measurement point registration

Place the receiver on the point to be measured. Make sure that the laser beam hits the target.



Live values are indicated with a green vertical line beside the values.



Touch the register icon to register the measurement point.

The colour indicates the status of the Y value in relation to the selected tolerance.



Within tolerance.



Positive values within double tolerance.




Negative values within double tolerance.



Positive values out of double tolerance.



Negative values out of double tolerance.



When a measurement point is registered, fixed values are indicated without a green vertical line beside the values.

## Note

A note with up to 20 characters can be entered at each point.





Touch the icon for entering a note.

## Neighbor points

It is possible to continue directly to a neighbor point in the measurement point screen. In other words, it is not necessary to return to the summary screen between each point.

Touch a neighbor point to go to it.

-  Unmeasured neighbor point.
-  Measured neighbor point.

## Remeasure a point



Touch the remeasure icon.

## Delete a point



Touch the delete icon.

## Return to summary screen



Touch the confirmation icon to return to summary screen.



## REFERENCES

There are different ways to select references.

### Manually selected reference points

One or three points can be selected in the measurement point screen.



Select point as reference.

### Reference points for positive values only

Selects reference points for positive values only. When selecting positive values only, suitable reference points are automatically selected. Can be selected in the summary screen. Use only after points has been measured.



Select reference points for positive values only.

### Reference points for negative values only

Selects reference points for negative values only. When selecting negative values only, suitable reference points are automatically selected. Can be selected in the summary screen. Use only after points is measured.



Select reference points for negative values only.

### Best fit

Contrary to the selection of reference points, best fit is a function that can be enabled or disabled. The function calculates a reference plane that minimizes the

deviation from measured points. In flatness, a minimum of three measured points is required in order for the function to be accessible. It is also required that not all the measured points lie on a straight line in order for the function to be accessible.

When the function is enabled, it will continuously recalculate a reference plane whenever the input parameters to the function are changed. These parameters are changed if a new point is measured, a point is remeasured, a measured point is removed or if a user given distance is changed. The best fit reference plane will however not be recalculated if the user aligns a measured point.



Enable the best fit function.




Update best fit calculations.



Disable the best fit function.

## MEASUREMENT RESULT









### Summary screen



Summary screen with up to 16 points on a circle.


The summary screen shows all the measurement points.

The symbols indicate status of the measurement point.

-  Values within tolerance.
-  Positive values within double tolerance.
-  Negative values within double tolerance.
-  Positive values out of double tolerance.
-  Negative values out of double tolerance.
-  Unmeasured point.
-  Reference point.
-  Inactive reference point.

Tolerance, maximum and minimum values and the difference between the maximum and the minimum values are also shown.

When there are more than 16 points on a circle, the points are shown with colour dots only.



Summary screen with more than 16 points on a circle and best fit.

Measurement values at each point can be seen in the measurement point screen or in the list screen.



Touch and release a point to open the measurement point screen.



Touch the list icon to go to list.


### Save measurement

The measurement can be saved anytime and be opened later.



Touch the save icon to save the measurement.

## List screen



A1	1100	0.0	-0.071	-0.995	0.5
A2	1100	22.5	-0.171	-0.749	0.5
A3	1100	45.0	-0.266	-1.406	0.5
A4	1100	67.5	-0.332	-1.547	0.6
A5	1100	90.0	-0.293	-0.884	0.5
A6	1100	112.5	-0.074	-1.583	0.5
A7	1100	135.0	-0.006	-1.922	0.5
A8	1100	157.5	+0.023	-0.815	0.5
A9	1100	180.0	+0.150	+0.293	0.5
A10	1100	202.5	+0.226	-0.672	0.5
A11	1100	225.0	+0.133	+1.049	0.5
A12	1100	247.5	+0.105	+0.784	0.5
A13	1100	270.0	+0.081	-1.372	0.5



Touch the summary screen icon to return to summary screen.

The list screen shows all the measurement points in a list with distances, values, and notes if any.

The list can be scrolled up and down with a finger or by using the arrows at the right.


## **Evaluating the result**

The result is presented in relation to the selected references. The direction is depending on how the receiver is placed. If the receiver is placed according to the mounting instructions, Y values are showing the vertical direction. In the vertical direction (Y), positive values mean that the measurement object at this point is higher than the reference plan, and negative values that the measurement object is lower than the reference plan.


These values are compared with the tolerance to determine whether correction is necessary. When a tolerance is selected, the symbols indicate if the values are within tolerance or not.

## ALIGNMENT

Select the point to be aligned in the summary screen.



Place the receiver on the point. Make sure that the laser beam hits the target.



Touch the alignment icon.

Note: Make sure that the receiver is placed in the correct position on the right point before confirming to go to live adjustment.



The actual Y value for the selected point goes live and alignment can be made towards zero. Zero will be in accordance to selected references.

Adjust vertically until the Y value for the selected measurement point is within tolerance.

The arrow show in which direction to adjust.




Confirm the alignment.

Note: Depending on your application, alignment at one point might affect other measurement points. It is therefore recommended to remeasure all points when all adjustments are made.



## FLANGE MEASUREMENT

Flange measurement is used when taper of a flange is to be measured.



When flange measurement is activated, an alternative list screen is shown.

In each row, the points at each circle position are shown next to each other. To their right, the taper is shown.

	Y <sub>A</sub>	Y <sub>B</sub>	Y <sub>C</sub>	Δ <sub>B-A</sub>	Δ <sub>C-B</sub>	Δ <sub>C-A</sub>	
1	0.0	-0.071	-0.102	0.000	-0.031	+0.102	+0.071
2	22.5	-0.171	-0.138	-0.123	+0.033	+0.015	+0.048
3	45.0	-0.266	-0.215	-0.185	+0.050	+0.031	+0.081
4	67.5	-0.066	-0.283	-0.079	-0.218	+0.205	-0.013
5	90.0	-0.293	-0.017	0.000	+0.276	+0.017	+0.293
6	112.5	-0.074	-0.052	-0.032	+0.022	+0.020	+0.042
7	135.0	-0.006	-0.064	-0.108	-0.058	-0.043	-0.102
8	157.5	+0.023	+0.108	+0.021	+0.085	-0.087	-0.002
9	180.0	+0.190	+0.224	+0.198	+0.034	-0.026	+0.008
10	202.5	+0.226	+0.250	+0.203	+0.024	-0.047	-0.023
11	225.0	+0.133	+0.220	+0.156	+0.087	-0.064	+0.023
12	247.5	+0.105	-0.119	+0.064	+0.015	-0.056	-0.041
13	270.0	+0.081	+0.012	0.000	-0.069	-0.012	-0.001

Example:

First row at 0.0°:

A1, B1, C1, A1-B1, B1-C1, A1-C1

Second row at 22.5°:

A2, B2, C2, A2-B2, B2-C2, A2-C2 etc

The taper can be shown in mm/mils or degrees/radians.

## OTHER FEATURES

### Sensor display

Sensor Display can be reached directly in the summary screen.



Starts Sensor Display.

See chapter "Sensor Display" in the FIXTURLASER NXA manual.

### Reference Receiver

A reference receiver, a second receiver, is used in applications where you want to check that the reference, the laser beam, has not moved during the measurement sequence.

The reference receiver is normally mounted at far distance from the laser transmitter to more easily detect any movements of the laser.

When the laser beam is adjusted to its final position and the reference is established, the values from the reference receiver are set to zero in the Sensor Display. It is possible, at any time during the measurement, to enter the Sensor Display and check that the values are still zero.

See chapter “Receiver R2” about connecting a reference receiver.





## **MEMORY MANAGER**

### **FILE MANAGER**

See chapter “Memory Manager” in the FIXTURLASER NXA manual.

### **SAVE MEASUREMENT**

See chapter “Memory Manager” in the FIXTURLASER NXA manual.

### **TRANSFER FILES TO A PC**

See chapter “Memory Manager” in the FIXTURLASER NXA manual.

Note: Apart from the picture file (jpeg) and a text file (txt), there will also be a list file (lst) in the PC for straightness and flatness measurements.

## STRAIGHTNESS MEASUREMENT



The screen displays measurement results, distances\*, tolerance, references, file name, date and time, serial number of the display unit and the sensor, program and program version.

\*) If the number of points exceeds 25, only the distance to the last point is shown.

It is possible to go directly to Straightness measurement to continue measuring. All measurement data will be uploaded.



Exits the measurement file.



Go to Straightness Measurement by touching this icon.

## RECTANGULAR FLATNESS MEASUREMENT



The screen displays measurement results, distances, tolerance, references, file name, date and time, serial number of the display unit and the sensor, program and program version.

It is possible to go directly to Rectangular Flatness Measurement to continue measuring. All measurement data will be uploaded.




Exits the measurement file.



Go to Rectangular Flatness Measurement by touching this icon.

## CIRCULAR FLATNESS MEASUREMENT



The screen displays measurement results, diameters, number of points on a circle, tolerance, references, file name, date and time, serial number of the display unit and the sensor, program and program version.

It is possible to go directly to Circular Flatness Measurement to continue measuring. All measurement data will be uploaded.



Exits the measurement file.




Go to Circular Flatness Measurement by touching this icon.



## RECEIVER R2

Receiver with two axes detector and inclinometer.



1. ON/OFF button with status indication LED
  - a. Continuously green – On
2. Micro USB for charging

3. Bluetooth indication LED
  - a. Continuously blue – paired and ready
  - b. Flashing blue – searchable/ready to pair
  - c. No light – Bluetooth disabled
4. Battery status button – press to instantly show the battery status (also works when the unit is switched off)
5. Battery status LED
  - a. One LED flashing red – less than 10% charge left
  - b. One LED double flashing red – less than 5% charge left
  - c. One LED continuously orange – charging
  - d. One LED continuously green – fully charged
6. Battery status LED when battery button is pressed
  - a. Continuously green – battery status
  - b. Rolling green – battery charging
7. Holes for fixtures
8. Serial number

## **OPERATING MODES**

The R2 unit has two operating modes: On and Off.

Turn the unit on and off by pressing the ON/OFF button firmly.

In case the unit fail to respond, it is possible to turn it off by pressing down the ON button for more than 10 seconds.

## **CONNECTIONS**

### **Bluetooth connection**

The main connection for R2 is the built in Bluetooth connection.

Bluetooth settings is described in the chapter “Global Settings” in the FIXTURLASER NXA manual.

To use an extra R2 as a reference receiver you need to pair the receivers in two steps. First search for and pair the measurement receiver, then search for and pair the reference receiver. The R2 with the uppermost position in the Bluetooth Settings list will be the measurement receiver.

## POWER SUPPLY

The R2 unit is powered by a high-capacity rechargeable Li-Ion cell, or by the external power unit.

The operating time of the battery is approximately 12 hours when the system is used for a typical measurement work (continuously on).

When the external power supply is connected, the unit will automatically start charging the batteries. This will be indicated by the first battery status LED turning orange, when the unit is fully charged the LED will turn green. By pressing the battery status button, the exact charging status can be monitored.

The charging time is approximately 8 hours for a fully drained battery. (Charging to 50%

takes approximately 2 hours.) The charging time will be longer if the unit is turned on while being charged.

When used in typical conditions the battery will sustain good capacity for approximately 2-3 years before needing replacement. Contact your sales representative for battery replacement.

The battery contains safety circuitry to operate safely with the unit. The unit can therefore only be used with the Li-Ion batteries supplied by FIXTURLASER. Improper replacement of batteries can cause damage and risk for personal injury. Please refer to the chapter on safety for further instructions.

## MOUNTING

### Mounting to magnetic base

The receiver is mounted on the magnetic base with extension fixture together with the receiver adapter and the rods.

Mount the receiver to the receiver adapter with the supplied screws. Mount the rods to the magnetic base with extension fixture. Slide the receiver on to the rods, as shown in picture.

Note: Make sure that the receiver is properly locked in its position.



## Mounting for full bore



## Mounting for half bore



## LASER TRANSMITTER T110

Battery powered laser transmitter of diode type with built-in micrometer screws for adjustment of the laser beam in horizontal and vertical level.



## LEVELLING

### Coarse adjustment

Untighten the lock ring.



### Fine adjustment

Tighten the lock ring.



Do not unscrew the fine adjustment further than the stop mark.

## MOUNTING

### Mounting to magnetic base

The T110 is mounted on the magnetic base together with the rod adapter, the rods and the universal bracket.

Mount the universal bracket to the T110 with the supplied screws. Mount the rod adapter on the magnetic base with the supplied screw. Attach the rods to the rod adapter, and then slide the universal bracket with the laser transmitter onto the rods, as shown in picture.





## Mounting to the transmitter beam fixture

Mount the T1110 to the transmitter beam fixture, as shown in picture.





## LASER TRANSMITTER T111

Laser transmitter of diode type with built-in micrometer screws for adjustment of the laser beam in horizontal and vertical level. The T111 is powered by the supplied AC-adapter (110/230 Volts).



## LEVELLING

### Coarse adjustment

Untighten the lock ring.



### Fine adjustment

Tighten the lock ring.



**NOTE:** Do not unscrew the fine adjustment further than the stop mark.

## **MOUNTING**

See T110.

## LASER TRANSMITTER T21

Battery powered laser transmitter of diode type. The laser transmitter has a built-in angular prism in a turret allowing the creation of a 360° laser plane. Laser beam levelling can be made in the X and Y coordinates as well as parallel adjustments. The turret can easily be detached giving a laser beam perpendicular to the X-Y plane.



## LEVELLING

### Coarse adjustment

Untighten the lock ring.



### Fine adjustment

Tighten the lock ring.



NOTE: Do not unscrew the fine adjustment further than the stop mark.

## MOUNTING

### Straightness

The T2I is mounted on the magnetic base together with the rod adapter and the rods.

Mount the rod adapter on the magnetic base with the supplied screw. Attach the rods, and then slide the T2I onto the rods, as shown in picture.



## Flatness

The T21 can either be mounted on a magnetic base or on a tripod.

When using the magnetic base, mount the rod adapter on the magnetic base with the supplied screw. Attach the T21 onto the adapter with the two supplied screws, as shown in picture.




On a tripod, use the supplied screws to attach the T21.



## CALIBRATION OF THE SPIRIT LEVELS


Position the T21 on a table with flat surface which is in level within 0.2 mm/m in both directions. Mark two positions for the receiver at a distance of 1 metre minimum from each other.



1. Min 1 metre between the detector positions.
2. Zero the levels with the micrometre screws.
3. Zero the value on the screen.
4. Read and note the displayed value.
5. Turn the T21 180°.
6. Turn the turret 180°.
7. Zero the levels with the micrometer screws.
8. Zero the value on the screen.
9. Read and note the displayed value.

The value at 9 should be the same (within 0.2 mm/m) as at 4 if the level for this axis is correctly adjusted. Any difference is divided

by two and then added to the lowest of these values, which results in the value R.




10. Adjust to the R value using the micrometer screws.
11. Check the zeroing, zero again and re-adjust to R if necessary.

12. Zero the level with the tool.
13. Turn the T2I 90°.
14. Turn the turret 90°.
15. Zero the level with the micrometer screws.
16. Adjust to the R value using the micrometer screws.
17. Check the zeroing.
18. Zero the level with the tool.

## LASER TRANSMITTER T220

Battery powered laser transmitter of diode type with built-in spirit levels and an angular prism. It is equipped with micrometer screws for adjustment of the laser beam in horizontal and vertical level. The optical head can be rotated 360° in order to project a reference plane with the laser beam.





1. Turret with built-in angular prism.
2. Laser apertures.
3. Horizontal spirit levels with adjustment screws.
4. Protractor with  $15^\circ$  increment.
5. Vertical spirit levels with adjustment screws.
6. Knob for rotating of optical head.
7. 4 batteries LR6. Pull the ends together and pull out the cassette.
8. Laser On/Off switch.
9. LED indicating laser transmitter activity.
10. Levelling, coarse adjustment. With lock ring.
11. Levelling, fine adjustment.
12. Direction selector for laser beam. Vertical or horizontal mode by turning ring.

## LEVELLING

### Coarse adjustment

Untighten the lock ring.



### Fine adjustment

Tighten the lock ring.



**NOTE:** Do not unscrew the fine adjustment further than the stop mark.

## ROTATING OF OPTICAL HEAD

### Coarse adjustment

Turn the knob to the right, to the red X.  
This will release the fine tuning.

Rotate the optical head until the laser beam is close to the detector.

### Fine adjustment

Turn the knob to the left, to the green check mark.  
This will connect the fine tuning screw.

Use the fine tuning to get the laser beam in the center of the detector.



## MOUNTING

### Straightness

The T220 can either be mounted on a magnetic base together with the angular bracket or be mounted on a tripod.

Mount the angular bracket on a magnetic base or on a tripod. Mount the T220 to the angular bracket, as shown in picture. Use the supplied screws.



## Flatness

The T220 can either be placed directly on the measurement object, be mounted on two magnetic bases together with the angular bracket or be mounted on a tripod.

Mount the angular bracket on two magnetic bases. Mount the T220 to the angular bracket, as shown in picture. Use the supplied screws.




Mount the T220 on a tripod as shown in picture. Use the supplied screws.






## CALIBRATION OF THE SPIRIT LEVELS

Position the T220 on a table with flat surface which is in level within 0.02 mm/m in both directions. Mark two positions for the detector unit at a minimum distance of 1 metre from each other.



1. Zero the levels with the micrometre screws.
2. Zero the value on the screen.
3. Read and note the displayed value.
4. Turn the T220 180° and turn the turret.
5. Zero the levels with the micrometer screws.
6. Zero the value on the screen.
7. Read and note the displayed value.

The value at 7 should be the same (within 0.02 mm/m) as at 3 if the level for this axis is correctly adjusted. Any difference is divided by two and then added to the lowest of these values, which results in the value R.



11. Turn the T220 90° and turn the turret.
12. Zero the level with the micrometer screws.
13. Adjust to the R value using the micrometer screws.
14. Check the zeroing.
15. Zero the level with the tool.

8. Adjust to the R value using the micrometer screws.
9. Check the zeroing, zero again and re-adjust to R if necessary.
10. Zero the level with the tool.

## TECHNICAL SPECIFICATION – FIXTURLASER R2

### Part. No. I-1121

Housing material	Anodized aluminum and ABS plastic
Operating temperature	0 to 50°C (32 to 122°F)
Storage temperature	-20 to 70°C (-4 to 158°F)
Relative humidity	10 – 90%
Weight	172 g (6.07 oz)
Dimensions	94 mm x 50 mm x 44 mm (3.7 in x 2.0 in x 1.7 in)
Environmental protection	IP 65
Detector	2-axis PSD
Detector size	20 mm x 20 mm (0.8 in x 0,8 in)
Detector resolution	1 $\mu$ m
Measurement accuracy	1% $\pm$ 3 $\mu$ m
Ambient light protection	Optical filtering and ambient light signal rejection
Inclinometer resolution	0.01°
Inclinometer accuracy	$\pm$ 0.1°

Wireless communication	Class I Bluetooth transceiver with multi-drop capability. BLE Bluetooth Low Energy (BT 4.0) and Classic Bluetooth.
Communication range	10 m (33 ft)
Connectors	1 USB Micro port (IP67); Charging: 5V, 0,5A
Power supply	High performance Li Ion battery.
Operating time	12 hours continuous use
Battery Charging time (system off, room temperature)	8 hours
Battery Capacity	10.4 Wh
LED indicators	Unit state, battery status and Bluetooth status.

Specifications are subject to change without notice.

## TECHNICAL SPECIFICATION – FIXTURLASER T110

### Part. No. I-0390

Housing material	Anodized aluminum
Operating temperature	0 to 50°C (32 to 122°F)
Storage temperature	-20 to 70°C (-4 to 158°F)
Relative humidity	10 – 90%
Weight	1100 g (2.43 lbs)
Dimensions	60 mm x 60 mm x 140 mm (2.4 in x 2.4 in x 5.5 in)
Laser	650 nm class II diode laser
Laser power	< 1 mW
Measurement distance	Up to 50 m (164 ft)
Power supply	2 batteries type LR6 (AA)
Warming up time	10 min
Operating time	15 hours



## TECHNICAL SPECIFICATION – FIXTURLASER T I I I

### Part. No. I-0285

Housing material	Anodized aluminum
Operating temperature	0 to 50°C (32 to 122°F)
Storage temperature	-20 to 70°C (-4 to 158°F)
Relative humidity	10 – 90%
Weight	1030 g (2.27 lbs)
Dimensions	60 mm x 60 mm x 140 mm (2.4 in x 2.4 in x 5.5 in)
Laser	650 nm class II diode laser
Laser power	< 1 mW
Measurement distance	Up to 50 m (164 ft)
Power supply	AC-adaptor 110/230 Volts
Warming up time	10 min






## TECHNICAL SPECIFICATION – FIXTURLASER T2I

### Part. No. I-0897


Housing material	Anodized aluminum
Operating temperature	0 to 50°C (32 to 122°F)
Storage temperature	-20 to 70°C (-4 to 158°F)
Relative humidity	10 – 90%
Weight	1150 g (2.54 oz)
Dimensions	100 mm x 103 mm x 109 mm (3.9 in x 4.0 in x 4.2 in)
Laser	650 nm class II diode laser
Laser power	< 1 mW
Measurement distance	Up to 20 m (66 ft)
Laser sweep flatness	±0.02 mm/m
Angular prism accuracy	±0.02 mm/m
Spirit level resolution	0.3 mm/m
Power supply	2 batteries type LR6 (AA)
Warming up time	10 min
Operating time	15 hours




## TECHNICAL SPECIFICATION – FIXTURLASER T220

### Part. No. I-0289

Housing material	Anodized aluminum
Operating temperature	0 to 50°C (32 to 122°F)
Storage temperature	-20 to 70°C (-4 to 158°F)
Relative humidity	10 – 90%
Weight	3500 g (7.72 lbs)
Dimensions	175 mm x 175 mm x 115 mm (6.9 in x 6.9 in x 4.5 in)
Laser	650 nm class II diode laser
Laser power	< 1 mW
Measurement distance	Up to 50 m (164 ft)
Beam deviation from levels	< 0.02 mm/m
Laser sweep flatness	±0.02 mm/m
Angular prism accuracy	±0.02 mm/m
Spirit level resolution	0.02 mm/m
Tilt adjustment from level	±15 mm/m
Power supply	4 batteries type LR6 (AA)
Warming up time	10 min
Operating time	15 hours





The built-in angular prism works as shown to the left. The incoming laser beam is deflected  $90^\circ \pm 0.02$  mm/meter also if the beam hits the prism obliquely.







Publication No. P-0252-GB

© 2019 ACOEM AB, Mölndal, Sweden

All rights reserved. No part of this manual may be copied or reproduced in any form or by any means without prior permission from ACOEM AB

[www.fixturlaser.com](http://www.fixturlaser.com)